

MTM700











PASS-THROUGH HARNESS INSTALL GUIDE

1.Mounting The Device

Securely install the device under the dash of vehicle using either a zip-tie, velcro, or double sided tape. (items not included)

Make sure the label-side is facing down and that their is no metal objects above the device or it will not operate correctly.

Make sure that the unit is kept free from direct exposure to elements such as heat & moisture. Do not tightly kink or wrap any excess cable.

Please use the diagram below for detail on the harness. Simply connect the harness, device & OBDII together via the molex connections.

Location of OBDII Install



Optional Pass-Through OBDII Install



2. Verify The Installation

Please verify the LED Lights are flashing correctly per the LED Diagram below. It may take 5 minutes to get a GPS lock. If you are unable to retrieve a signal after waiting a minute or two, reposition the unit and try again. Make sure you are not installing the device within a steel roof building as that may effect the connection.

LED	MEANING
Off	Check Wires Are Connected Properly
Good Connection	Solid Orange (CELL) Solid Green (GPS)
Bad Connection	Flashing Orange Flashing Green



3. Test The Installation

- 1. Log into the installer app.
- 2. Enter the SN# on the device & click search.
- 3. Enter the vehicles info & click save.
- 4. Click Test GPS to test the install. (may take up to 3 minutes)
- 5. Click Refresh to update the Test.

*Note - to create installer credentials, please have your account administrator create them on the account settings tab within the main account.